



© Alle Rechte bei Robert Bosch GmbH auch für den Fall von Schutzrechtsmängelungen, jede Veräußerungs- befugnis, wie Kopier- und Weitergaberecht, bei uns.

© This drawing is the exclusive property of ROBERT BOSCH GmbH. Without their consent it may not be reproduced or given to third parties.

Further foreign langu. drawings



Injectors (B 445 xxx xxx)
 Firing order 8 cyl.:
 1 5 4 2 6 3 7 8
ECU control order: (SV = Solenoid valve)
 for 8 Cyl.:
 Injector SV11 SV21 SV12 SV22 SV13 SV23 SV14 SV24



For the function of the ECU the vehicle configuration according to terminal diagram is mandatory

Remarks:
 Harness guidelines
 K5/ESK2 Y 281 E22 013E.
 DS-CV/ESA Y 445 R90 613
 ∞ = twisted pair recommended also recommended for all actuators
 Vx = Butt connector
 ----- = optional functions / nu = not used

Rev. DWG not extern. dist'd/		Non-Int. dimensions		ISO E		Scale		Mass	
±		mm, ±		☺					
0 462 YU4 08S		Gr.St. Volume		Date/		Name/		Title/	
1		1		Mar/31/2011		Manjushree		Terminal diagram	
2		2		Mar/31/2011		Praneetha		EDC7UC31-14.J0	
No.		Add.ETS and updated WFS pin		DS-SX/ENG1		Orig. Original:		No./	
1		First Edition		Ms. Mar/31/2011		ROBERT BOSCH		0 462 YU4 08S	
2		Sep/10/2013		Pr.		STUTTGART		Sheet 8	
3		valid		ck.				Sh/ 8	
Rep. f./						Rep. by/			